

1 RUN THE APP (iPhone/Android)



1. Download the **Bullseye Target Manager** APP from the Apple App Store or Google Play Store
2. Power on Target Camera (see step 2)
3. Connect to the **BullseyeCam WIFI** network as you would any WIFI network. (SSID located under transmitter)
4. Launch the App and select **New Session** and click **Yes** and you will see your live target.
5. After you shoot, press the **Show Shot** button to see Your Shot!

2 Power on Camera

Turn main camera power switch on. LED on left will turn orange when on.



3 Place Camera 8 – 15 feet from Target

Use telescoping legs and swivel head to adjust camera as needed to view target




4 Place WiFi Transmitter in Upright Position

Unlock tension handle. Pull up on lip of transmitter found on topside of device. Adjust accordingly and secure tension handle.

Features

LEDs for Night Viewing

Dusk approaching? No need to hurry. Turning Auto Night Mode on activates a light sensor that will automatically turn LEDs on in low light conditions.



Wi-Fi Transmitter LED Indicators

Allows for easy verification of power and signal strength



Easy Positioning

Telescoping legs fold from under camera to easily angle camera from 15 – 25 degrees.

Joint swivel camera head rotates 15 degrees in each direction.

These two combined make it easy to capture your target!

